Pull tilt adjustment

revised Nov 13, 2010





- Pull lever towards
 you to unlock the tilt
 & hold in the
 unlocked position
 (bottom picture)
- Adjust the tilt
- Release the lever to lock the tilt